

## MILLIAMP LOOP DIAGNOSTIC CALIBRATORS

**Model No: 532**

**Pyrosales Part No: PIE-532**

**Calibrate milliamp and voltage instruments**

Source to 24.000mA and 24.000 Volts DC; read 0.000 to 24.000mA, 0.000 to 24.000V, and 24.01 to 30.00V. Simulate 2-wire transmitters; power and read 2-wire transmitters; 250Ω resistor – HART compatibility.

**Calibrate with confidence**

Current: accurate to  $\pm(0.012\%$  of reading +0.002mA);  
Voltage: accurate to  $\pm(0.012\%$  of reading +0.004V).

**Troubleshoot loops and find ground faults**

Patented loop diagnostics take dynamic loop readings under operating conditions. Automatic indication of loop current, DC voltage, resistance, and leakage current. Displays AC voltage and presence of HART.

**Locate loop current leakages**

Find ground current leakage, faulty wiring, flooded conduits, and corrosion bridges.

**Faster Calibrations**

Select three outputs with EZ-CHECK switch. Two speed EZ-DIAL plus stepping and ramping.

**Includes attached test leads and carry case (020-0204)**

**Optional accessories**

AC Adaptor for 120VAC (020-0101);  
AC Adaptor for 240VAC (020-0100).



**CE Approved**