

## FREQUENCY CALIBRATOR

**Model: 541**

**Pyrosales Part No: PIE-541**

**Calibrate flow meters and frequency instruments**

Generate sine waves, zero-based and zero-crossing square waves; adjust amplitude from 100mV to 12V peak-to-peak.

**Read with built-in frequency counter**

Measures waveforms from 0.1V-120V peak-to-peak.

**Calibrate with confidence**

Accurate to  $\pm 0.005\%$  of range

**Compatible with process signal ranges**

0.001kHz to 20.000kHz; 0.1Hz to 2000.0Hz; 0.01Hz to 200.00Hz.

0.1CPM (counts-per-minute) to 2000.0CPM; 1CPH (counts-per-hour) to 20000CPH.

**Calibrate totalisers**

Totalise inputs/outputs from 1 to 99999 counts in 0.1 to 100.0 minutes.

**Includes attached leads and carry case**

**Optional Accessories**

AC Adaptor for 120VAC (020-0101);

AC Adaptor for 240VAC (020-0100).



**CE Approved**