# RTD DATA SHEET
# EXD-ISB/ISE




**EX-ISB-□-□-□-□-□-□-□-□-□-□-□-□-□**

**12 THREAD TYPE**
B=BSP, N=NPT

**11 THREAD SIZE**
C=1/2"

**10 FITTINGS**
S=SS

**9 HEAD TYPE** (Refer Data sheet)
LB=LH2, LB*=LH2(Ex d) FOR TB
LT=LH2, LT*=LH2(Ex d) FOR TX

**8 TYPE**
2=2-Wire, 3=3-Wire, 4=4-Wire

**7 TEMPERATURE RANGE**
H=>250°C, L=<250°C

**6 CALIBRATION**
A=Pt100-Din

**5 No OF ELEMENTS**
S=Single, D=Duplex

**4 SHEATH**
A=316SS

**3 LENGTH 'L'**
(In mm)

**2 DIAMETER**
3, 6, 8mm

**1 SENSOR TYPE**
R= RTD

Note 1: If RTD is to be used with a thermowell, please nominate
**Type: __, 'U' Length: _____, 'T' Length: _____** (Refer Thermowell data sheets)

## SELECTION

**EXD-ISB - R - __ - _____ - A - __ - A - __ - ___ - __ - S - __ - __**
1 2 3 4 5 6 7 8 9 10 11 12

**Special Requirements:** _____ **Note: ISB/ISE are interchangeable**



www.pyrosales.com.au

Pyrosales NSW
4 Wordie Place
PADSTOW NSW 2211
Tel: (02) 9790 1988
Fax: (02) 9790 1040
Email: sales@pyrosales.com.au

Pyrosales Victoria
Factory 4 Enterprise Way
BAYSWATER VIC 3153
Tel: (03) 9729 2100
Fax: (03) 9720 5559
Email: vicsales@pyrosales.com.au

Pyrosales Queensland
Unit 1, Lot 3, 70 Flanders Street
SALISBURY QLD 4107
Tel: (07) 3277 9400
Fax: (07) 3277 9495
Email: qldsales@pyrosales.com.au